

# deconex® de-coat 301L

## Activator-Component of the two-component reaction stop system

Stops the decoating reaction of potassium permanganate on HSS and Carbide

Suitable for use in immersion baths



### Usage

The two-component reaction stop system consists of the powdery primer deconex® de-coat 301P and is used together with the liquid activator **deconex® de-coat 301L** to stop the decoating reaction when using potassium permanganate solutions after removal of the following layers:

- CrN
- AlCrN
- AlCrN/SiN

Discolorations (manganese dioxide) on the substrates are removed and a carryover of potassium permanganate into the waste water is prevented.

In order for the reaction stop system to be implemented, certain technical requirements must first be met. We recommend that you get in touch with us regarding this.

### Application

The following application conditions have been found to be effective in practice:

Product	Dosage	Temperature	Exposure time
deconex® de-coat 301P (Primer)	14 g/L	20-25 °C	HSS: 2 - 3 min Carbide: 1 min
<b>deconex® de-coat 301L (Activator)</b>	160 mL/L	20-25 °C	HSS: 2 - 3 min Carbide: 1 min

### Ingredients

deconex® de-coat 301P Primer:  
Organic acids, dispersing agents

**deconex® de-coat 301L Activator:**  
Corrosion inhibitors, dispersing agents

# deconex® de-coat 301L

## Instructions for use

For the implementation please use our instructions for use.

Only compensate for losses due to evaporation with demineralised water!

A fine cleaning should be carried out after treatment. We will recommend a cleaning system to you that is adapted to our deconex® products.

## Neutralisation/disposal

Please refer to our disposal instructions for information on disposal.

## Chemical-physical data

deconex® de-coat 301P		
pH value	1% in demineralised water	approx. 3.2
Appearance	Powder	cream white

deconex® de-coat 301L		
pH value	1% in demineralised water	approx. 8.9
Density	Concentrate	1.05 g/mL
Appearance	Concentrate	Clear, colourless to yellow

## Delivery

Please ask your representative regarding current container sizes.

Containers, screw caps, seals and labels are made from recyclable polyethylene.

It should be noted: The used decoating solution must be disposed of professionally by a disposal company. The safety data sheets of the individual products can be used for this purpose. Locally applicable waste water and disposal regulations must be complied with.

## Material compatibility

Suitable for:

- HSS
- Carbide

Independent compatibility tests should be carried out on materials other than those specified or requested from Borer Chemie AG.

## Additional information

Information regarding safety in the workplace, storage, disposal and waste water treatment can be found in the safety data sheets as well as in the instructions for use and disposal instructions for this product.

For professional use only.

For more information about the product and its use, please contact your supplier or Borer Chemie AG.

Benefit from our expertise! Ask us for practical information about your specific application.

### Manufacturer:

#### Borer Chemie AG

Gewerbestrasse 13, 4528 Zuchwil / Switzerland  
Tel +41 32 686 56 00 Fax +41 32 686 56 90  
office@borer.ch, www.borer.swiss

All information provided is based on our knowledge as it currently stands, however it does not constitute any guarantee of product properties and does not form the basis of any legal relationship.